



Using a USB Keyboard with MyTana Cameras

Using a USB Keyboard lets you change the overlays on your recordings



- Add, change or move **Custom Titles**
- Replace the time/date stamp with **Custom Text**

You can also change the **File Names** of your videos and images


(see back)



GETTING STARTED

- ▶ Attach the keyboard to one of the USB ports on your system
- ▶ Use the arrow   buttons on the control panel to toggle to (select) any menu item on the main screen— indicated by the >

Main Screen



Custom Titles

Entering a Custom Title

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Secondary Overlay**, then **MENU/OK**
- Select **Title**, then **MENU/OK**
- Enter your title using the keyboard. If a 2nd line is needed, push **MENU/OK** to move cursor to the second line for typing
- Push **STOP BACK** repeatedly to return to the Main Screen

Reposition Title on the screen

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Title Overlay**, then **MENU/OK**
- Select movement you need, then press **MENU/OK** repeatedly until the title is in your desired location
Use the ▲▼ buttons to toggle between the movement choices
- Push **STOP BACK** repeatedly to return to the Main Screen

Remove a Title

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Title Overlay**, then **MENU/OK**
- Select **Edit Text**, then **MENU/OK**
- Use backspace or Delete/Back on the keyboard to delete the title, then **MENU/OK**
- Push **STOP BACK** repeatedly to return to the Main Screen

Custom Text

Adding Custom Text

Replaces date/time stamp at bottom of screen

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Set Up Primary Overlay**, then **MENU/OK**
- Select **Custom Text**, then **MENU/OK**
- 5 custom text lines appear, select one then push **MENU/OK**
Each selection allows 2 lines with 20 characters each
- You can enter all 5 custom names while you are here, or just one at a time
- Push **STOP BACK** repeatedly to return to the Main Screen

Reposition Custom Text on the screen

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Set Up Primary Overlay**, then **MENU/OK**
- Select **Title Overlay**, then **MENU/OK**
- Select movement you need, then press **MENU/OK** repeatedly until the title is in your desired location.
Use the ▲▼ buttons to toggle between the movement choices
- Push **STOP BACK** repeatedly to return to the Main Screen

Delete Custom Text on a job

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Set Up Primary Overlay**, then **MENU/OK**
- Select **Custom Text**, then **MENU/OK**
- Select custom text to remove, then **MENU/OK**
- Use backspace or Delete/Back keys to delete the title, then **MENU/OK**
- Push **STOP BACK** repeatedly to return to the Main Screen

Custom Text continued on back:

- Replacing the custom text with a date/time stamp
- Finding jobs with custom text

Custom Text (continued)

To Replace Custom Text with a time/date stamp

(No Keyboard Needed)

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Set Up Primary Overlay**, then **MENU/OK**
- Select **Text**, then **MENU/OK**
- Select **AdAt**, then **MENU/OK**
Time/date stamp will display with CURRENT time/date
- Push **STOP BACK** repeatedly to return to the Main Screen

To Find jobs with Custom Text

(No Keyboard Needed)

- Push **MENU/OK** on control panel to access the Main Screen
- Select **Overlay**, then **MENU/OK**
- Select **Set Up Primary Overlay**, then **MENU/OK**
- Select **Custom Text**, then **MENU/OK**
- Choose the job you want to record that you have already named, then **MENU/OK** To display text, push **MENU/OK**
- Push **STOP BACK** repeatedly to return to the Main Screen and continue with recording

File Names

To Change a File Name

Replaces the default file name (ex: **20171116-01.mp4**) with your own text. Consider using what you used for Custom Title or Custom Text.

File names appear on your USB drive lists, or will display in Play Video Screen

- Push **MENU/OK** on control panel to access the Main Screen
- Select **File Management**, then **MENU/OK**
- Select **Rename**, then **MENU/OK**
- Select **Internal**, **External** or **Both**, then **MENU/OK**
- Rename files
****Important** Type in **.mp4** at the end of the file name for videos, or **.jpg** at the end of the file name for snapshots– be sure to include the **.** (dot) Press **MENU/OK**
- Push **STOP BACK** repeatedly to return to the Main Screen



Time

To Change Time Format

(No Keyboard Needed)

- Select **Overlays**, then **MENU/OK**
- Select **Primary Overlay**, then **MENU/OK**
- Select **Time Format**, then **MENU/OK**
- There are 7 options to choose from, Select **HH:MM AM/PM**, then **MENU/OK**
- Push **STOP BACK** repeatedly to return to the Main Screen



Manufacturers of
Quality Sewer & Drain
Cleaning Equipment
since 1957

www.MyTana.com
746 Selby Ave
St. Paul MN, 55104
fax: 651.222.1739

1.800.328.8170
Factory Direct Customer Service
Mon – Fri 7am – 5pm CST
Competent • Polite • Clear